REMARKS:

LOAD and LOAG: Departures in direction west may call "WIEN INFORMATION" 134.625 MHZ. In all other directions departures may call "WIEN INFORMATION" 118.525 MHZ.

LOGM: Departures in direction east or north-east may call "WIEN INFORMATION" 118.525 MHZ. Departures in direction south may call "WIEN INFORMATION" 124.400 MHZ and for all other directions "WIEN INFORMATION" 134.625 MHZ.

LOGO und LOGI: Departures in direction north may call "WIEN INFORMATION" 134.625 MHZ. In all other directions departures may call "WIEN INFORMATION" 124.400 MHZ.

LOGP: Departures in direction north may call "WIEN INFORMATION" 118.525 MHZ. In all other directions departures may call "WIEN INFORMATION" 124.400 MHZ.

Departures from aerodromes located close to the State boundary can call the respective foreign FIS unit directly (e.g. DEP LOGG with destination in Hungary contacts Budapest Information) unless other regulations apply (e.g. entering of ATC clearance requiring airspace).

For details and lateral limits of the FIC areas see ENR 2.2

REMARK:

This chart is valid during daytime (0700 - 2100 local time) outside of the responsibility of the respective ATC units according ENR 6.6.

Between 2100 - 0700 (local time):
* contact 124.400 MHZ and wait for further information/ instruction, or
* call respective ATC unit situated above the current position.



CHANGE: EDITORIAL